

LEAVE ALL BOLTS LOOSE UNTIL ALL ARE IN PLACE.

1. LAY THE THREE TOP PLANKS ON THE GROUND CLOSE TOGETHER. (NOTE FOR 8' TABLE: THE DOUBLE BAR ASSEMBLIES ATTACH TO THE SEAT PLANK GROOVES. THE (3) TOP PLANKS HAVE BARS IN THEM). TIP THEM ON THEIR SIDE ONE AT A TIME AND INSERT THE 2 1/4" CARR. BOLTS THROUGH ALL THE HOLES EXCEPT THE CENTER HOLE ON THE MIDDLE PLANK. THIS HOLE GETS A 3" CARR BOLT.
2. PLACE A SET OF LEGS UPSIDE DOWN, LINING UP THE HOLES WITH THE BOLTS. TIGHTEN WITH 3/8" LOCKWASHERS AND NUTS PROVIDED. REPEAT ON OTHER END. BE SURE TOP ANGLES FACE TOWARD THE CENTER.
3. ATTACH THE CENTER BAR AT THIS TIME ALSO. THEN SECURE THE BRACES IN THE MIDDLE AND AT THE LEG SPACER. (1" HEX BOLT)
4. TURN THE TABLE OVER & ATTACH SEAT PLANKS WITH 2 1/4" CARR BOLTS. PUT DOUBLE BAR ASSEMBLIES IN GROOVES BEFORE BOLTING.

