

## ASSEMBLY DRAWING MODEL #:6J2GVP

### LEAVE ALL BOLTS LOOSE UNTIL ALL ARE IN PLACE.

1. LAY VINYL PLASTISOL TOP UPSIDE DOWN ON A NON-ABRASIVE SURFACE. SET A TABLE LEG ON THE TABLE TOP. LINE UP THE TOP ANGLE HOLES WITH THE PREDRILLED HOLES. ATTACH WITH  $3/8" \times 1 1/4"$  HEX BOLT & FLAT WASHER ON TABLE TOP SIDE AND LOCKWASHER & NUT ON TOP ANGLE SIDE.
2. CONNECT THE BRACES TO THE PREDRILLED CENTER HOLE(S) AND THE LEG SPACER.
3. TURN TABLE OVER AND ATTACH THE SEAT PLANKS.

