

ASSEMBLY DRAWING

MODEL #:62BGA

LEAVE ALL BOLTS LOOSE UNTIL ALL ARE IN PLACE.

1. BOLT THE LEGS TOGETHER AS SHOWN WITH THE BRACE BETWEEN THE LEGS, AND THE TOP ANGLE AND SEAT ANGLES FACING THE SAME WAY. NOTICE THERE IS A LEFT AND RIGHT SEAT ANGLE. ATTACH APPROPRIATELY. THE BENT END OF BRACE POINTS AWAY FROM THE LEG.
2. LAY THREE PLANKS ON THE GROUND CLOSE TOGETHER. PUT HOLD DOWN CLIPS INSIDE PLANK.
3. PLACE A SET OF LEGS UPSIDE DOWN. PUT BOLTS THROUGH HOLD DOWN CLIP AND TIGHTEN W/ FLANGE NUTS. REPEAT FOR THE OTHER END OF THE TABLE. BE SURE THE TOP ANGLES FACE TOWARD THE CENTER.
4. ATTACH THE SEAT PLANKS WHILE THE TABLE IS UPSIDE DOWN.
5. ATTACH CENTER CLEAT THE SAME WAY.
6. CONNECT THE BRACES TO THE CENTER CLEATS.
7. ATTACH END CAPS AS SHOWN BELOW.

