

ASSEMBLY DRAWING MODEL #:82BGVP

LEAVE ALL BOLTS LOOSE UNTIL ALL ARE IN PLACE.

1. BOLT THE LEGS TOGETHER AS SHOWN WITH THE BRACE BETWEEN THE LEGS, AND THE TOP ANGLE AND SEAT ANGLES FACING THE SAME WAY. NOTICE THERE IS A LEFT AND RIGHT SEAT ANGLE. ATTACH APPROPRIATELY. THE BENT END OF BRACE POINTS AWAY FROM THE LEG.
2. LAY VINYL PLASTISOL TOP UPSIDE DOWN ON A NON-ABRASIVE SURFACE. SET A TABLE LEG ON THE TABLE TOP. LINE UP THE TOP ANGLE HOLES WITH THE PREDRILLED HOLES. ATTACH WITH $3/8"$ x $1 1/4"$ HEX BOLT & FLAT WASHER ON TABLE TOP SIDE AND LOCK WASHER & NUT ON TOP ANGLE SIDE.
3. CONNECT THE BRACES TO THE PREDRILLED CENTER HOLE(S).
4. TURN TABLE OVER AND ATTACH THE SEAT PLANKS.

