POLYWOOD®
Intelligent Design™

Model: ECA15

__(1) Seat
__(1) Back
__(2) Front legs
__(2) Arms
__(1) Long brace
__(1) Short brace
__(1) Hardware pack

TOOLS NEEDED




7/16 Wrench
4mm HEX KEY, ALLEN, T-HANDLE
(INCLUDED)


Qty.	Description
8	A- 27 X 2 SOCKET WAFER A
6	B-1/4-20 X 1-7/8 WAFER SHCS
2	C-1/4-20 X 2-1/4 WAFER SHCS
8	D-1/4 FLAT WASHER
8	E-1/4-20 NYLOCK NUT

Step 1
Attach front legs to seat using (6) 1-7/8" bolts, nuts and washer

Attach long brace using (2) 2" screws




Step 2
Attach arms to front leg using (2) 2-1/4" bolts, nuts and washer




Step 3
Attach back to seat using (2) 2" screws

Attach back to arm using (2) 2" screws



Step 4
Attach short brace to rear leg using (2) 2" screws



ASSEMBLY INSTRUCTIONS

ALL HARDWARE IS STAINLESS STEEL

11/28/2012

FURNITURE LEISURE INC
1.800.213.2401

www.FurnitureLeisure.com
www.PicnicFurniture.com
www.ParkTables.com
www.PoolFurnitureSupply.com
www.PicnicTableSupplier.com
www.UBrace.com

POLYWOOD®
Intelligent Design™

FURNITURE LEISURE INC
1.800.213.2401

www.FurnitureLeisure.com
www.PicnicFurniture.com
www.ParkTables.com

www.PoolFurnitureSupply.com
www.PicnicTableSupplier.com
www.UBrace.com

ECA15 - Long Island Adirondack Chair [39 lbs]

