POLYWOOD®
Intelligent Design™

Model: ECD24

__(1) Seat
__(1) Back
__(2) Front legs
__(2) Back legs
__(2) Arms
__(1) Footrest
__(1) Short brace
__(2) Side brace
__(2) Braces
__(1) Hardware pack


TOOLS NEEDED




7/16 Wrench
4mm HEX KEY, ALLEN, T-HANDLE
(INCLUDED)

Qty.	Description
8	A-.27 X 2 SOCKET WAFER A
4	B-.27 X 3 SOCKET WAFER A
8	C-1/4-20 X 1-7/8 WAFER SHCS
4	D-1/4-20 X 2-1/4 WAFER SHCS
12	E-1/4 FLAT WASHER
12	F-1/4-20 NYLOCK NUT

Step 1
Lay seat on its side.
Attach front leg and back leg to seat. Now flip seat around and do the other side. Uses (8) 1-7/8" bolts, nuts and washer




Step 2
Attach arms to front leg using (2) 2-1/4" bolts, nuts and washer
Attach braces to legs using (4) .27x2" wafer screws




Step 3
Attach back to seat using (2) .27x2" screws

Attach back to rear leg using (2) .27x3" screws



Step 4
Attach footrest to side braces using (2) .27x2" screws
Attach sidebrace to front legs using (2) 2-1/4" bolts, nuts, washer
Attach short brace to sidebrace using (2) .27x3" screws



ASSEMBLY INSTRUCTIONS


ALL HARDWARE IS STAINLESS STEEL

11/28/2012

FURNITURE LEISURE INC
1.800.213.2401

www.FurnitureLeisure.com
www.PicnicFurniture.com
www.ParkTables.com
www.PoolFurnitureSupply.com
www.PicnicTableSupplier.com
www.UBrace.com

ECD24 - Long Island Counter Height Dining Chair [36 lbs]



POLYWOOD®
Intelligent Design™