

RECTANGLE HIP SHADE

## 20' x 30' x 10'

MODEL #: RD203010SG (With Glide Elbows) RD203010SN (Without Glide Elbows)

REF.#	PART DESCRIPTION	QTY.
1	Ø5.5"Capped Surface Mount Column	4
2	Angled Elbow	4
3	Ø2.88"Hip Rafter w/ Swaged End	4
4	Ø2.88"Ridge Pole w/ Swaged Ends	1
5	Rectangle "Y" Connection	2
6	Fabric Cover w/ Cable Insert	1
7	Frame Hardware Kit	1







PicnicFurniture.com ParkTables.com


FurnitureLeisure.com PoolFurnitureSupply.com PicnicTableSupplier.com **UBrace.com** 


RECTANGLE HIP SHADE


20' x 30' x 10'

MODEL #: RD203010IG (With Glide Elbows) RD203010IN (Without Glide Elbows)

REF.#	PART DESCRIPTION	QTY.
1	Ø5.5"Capped Embedded Column	4
2	Angled Elbow	4
3	Ø2.88"Hip Rafter w/ Swaged End	4
4	Ø2.88"Ridge Pole w/ Swaged Ends	1
5	Rectangle "Y" Connection	2
6	Fabric Cover w/ Cable Insert	1
7	Frame Hardware Kit	1









PicnicFurniture.com ParkTables.com

FurnitureLeisure.com PoolFurnitureSupply.com PicnicTableSupplier.com **UBrace.com**