

## **FURNITURE LEISURE INC**

OUR LIST OF WEB STORES

www.FurnitureLeisure.com www.PicnicFurniture.com www.ParkTables.com www.PoolFurnitureSupply.com www.PicnicTableSupplier.com www.UBrace.com

1.800.213.2401

## POLY DOGIPOT® JUNIOR BAG DISPENSER (ITEM #1007-2)

SPECIFICATION, INSTALLATION AND OPERATION SHEET



#### YOUR POLY DOGIPOT® JUNIOR BAG DISPENSER INCLUDES:

- One (1) Poly DOGIPOT® JUNIOR Bag Dispenser
- Mounting hardware (one (1)  $2\frac{1}{4}$ " x  $\frac{1}{4}$ " shoulder bolt and one (1)  $2\frac{1}{2}$ " x  $\frac{1}{4}$ " bolt, washers and locknuts)
- Two (2) keys for Dispenser locking bottom access tray / insert
- Two (2) rolls of **DOGIPOT**® Smart Litter Pick Up Bags™ (ITEM #1402) (200 count per roll), installed in **DOGIPOT**® Junior Bag Dispenser

PLEASE CHECK THE ABOVE INVENTORY AND CALL YOUR DISTRIBUTOR IF ANY PARTS ARE MISSING.

#### INSTALLATION AND OPERATION INSTRUCTIONS

- 1. Select a good visible spot in your community or park where you want to install the Poly **DOGIPOT®** JUNIOR Bag Dispenser, such as on a post, building wall, tree, fence post, street sign post, etc. **The recommended installation height of the Poly DOGIPOT®JUNIOR Bag Dispenser is 66"** (5'6").
- 2. Remove the two keys from the back of the Dispenser. Insert key into the universal cam lock on the bottom access panel and turn one quarter to the right or left. Carefully, pull the bottom compartment down to release it from the body of the Dispenser.
- 3. The Dispenser has two pre-drilled holes; one on top for installation with the 2¼" x ¼" shoulder bolt and one through the interior back wall for installation with the 2½" x ¼" regular bolt. These two holes and the mounting hardware included match with the holes of every standard channel or square telescopic mounting post. **USE EXTERIOR WASHER BETWEEN SHOULDER BOLT HEAD AND DISPENSER WHEN INSTALLING. DO NOT OVER-TIGHTEN TO AVOID POSSIBLE CRACKING OF DISPENSER UNIT.**
- 4. To refill the Dispenser with **DOGIPOT®** Smart Litter Pick Up Bags<sup>™</sup>, take two (2) boxed rolls, and tear off the perforated seal from each box. Place the two boxes on top of each other on the bottom compartment shelf with the opening of the boxes facing the front. Reinstall the bottom locking access tray / insert.
- 5. Reach through the two diamond shaped openings and find the raw edge of the first bag through each of the slots and pull until the **DOGIPOT®** logo is visible.
- 6. ENJOY WATCHING PET OWNERS PICK UP AFTER THEIR DOGS!



# **FURNITURE LEISURE INC**

### **OUR LIST OF WEB STORES**

www.FurnitureLeisure.com www.PicnicFurniture.com www.ParkTables.com www.PoolFurnitureSupply.com www.PicnicTableSupplier.com www.UBrace.com

1.800.213.2401

## POLY DOGIPOT® JUNIOR BAG DISPENSER (ITEM #1007-2)

SPECIFICATION, INSTALLATION AND OPERATION SHEET

- POLY DOGIPOT® JUNIOR BAG DISPENSER (ITEM #1007-2)
  - H: 17" x W: 10" x D: 3"
  - 2.5 mm ABS / PP forest green polyethylene
  - Weight: 5 lbs.
  - 400 bag capacity
  - Two diamond shaped bag dispenser slots
  - · Bottom locking access tray / insert
  - Clearly posted instructions
- DESIGNED TO MOUNT ON 2" X 2" POLY, STEEL SQUARE OR CHANNEL POST
  - Mounting hardware included
- CAN ALSO BE MOUNTED ON FENCE, WALL, WOOD AND CHANNEL POST
  - · Hardware not included
- TWO (2) ROLLS OF DOGIPOT® SMART LITTER PICK UP BAGS™
  - 200 count per roll

TOTAL SHIP WEIGHT: 5 LBS.

