





ASSEMBLY DRAWING

MODEL #:RTRCF

1. TURN FIBERGLASS TOP UPSIDE DOWN & PLACE ON A NON-ABRASIVE SURFACE. ATTACH ALL LEGS TO THE TOP WITH 2 3/4" HEX BOLTS. SEE FIGURE 2. ONLY FINGER TIGHTEN BOLTS AT THIS TIME.
2. ATTACH THE BOTTOM RING TO THE BOTTOM OF THE LEGS WITH 2 3/4" HEX BOLT AS SHOWN IN FIG. 3. FINGER TIGHTEN.
3. TURN THE TABLE OVER AT THIS TIME. ATTACH EACH SEAT TO THE LEGS AS SHOWN IN FIGURE 4 USING 5/16" x 1" BOLTS. TIGHTEN ALL BOLTS AT THIS TIME.

FIG. 1



FURNITURE LEISURE INC

OUR LIST OF WEB STORES

www.FurnitureLeisure.com
www.PicnicFurniture.com
www.ParkTables.com

www.PoolFurnitureSupply.com
www.PicnicTableSupplier.com
www.UBrace.com

1.800.213.2401