

FURNITURE LEISURE INC


1.800.213.2401

www.FurnitureLeisure.com
www.PicnicFurniture.com
www.ParkTables.com

www.PoolFurnitureSupply.com
www.PicnicTableSupplier.com
www.UBrace.com


NCT44 - Dining Table [80 lbs]

Top View



42 1/2"

42 1/2"



29"



Intelligent Design™


Model:

NCT44, NCCT44,
NCRT44, NCBT44

- (1) Table top
- (4) Leg
- (2) Foot
- (2) Brace
- (1) Hardware pack


Step 1

Attach feet to legs using (4) 3/4" Chair bolts.




Step 2

Lay table top on flat surface.
Attach the leg assemblies to the table frame using
(8) .27x2 1/2" screw *Do not tighten until last step



Step 3


Attach the leg braces to the leg assemblies using
(4) .27x3" screw



Step 4

Set table upright and tighten all bolts.

Removable table plug
included in table.



TOOLS NEEDED

4mm HEX KEY: INCLUDED

Qty.	Description
8	A - .27 X 2-1/2 SOCKET WAFER A
4	B - .27 X 3 SOCKET WAFER A
4	C - 1/4-20 X 3-1/4 WAFER SHCS

