


SBD12 - South Beach Kid Chair [21 lbs]



FURNITURE LEISURE INC
1.800.213.2401

www.FurnitureLeisure.com
www.PicnicFurniture.com
www.ParkTables.com

www.PoolFurnitureSupply.com
www.PicnicTableSupplier.com
www.UBrace.com



Intelligent Design™

Model: SBD12

- (1) Seat
- (1) Back
- (2) Front legs
- (2) Back legs
- (2) Arms
- (2) Braces
- (1) Hardware pack

TOOLS NEEDED




7/16 Wrench
4mm HEX KEY, ALLEN, T-HANDLE
(INCLUDED)

Qty.	Description
6	A-.27 X 2 SOCKET WAFER A
2	B-.27 X 3 SOCKET WAFER A
6	C-1/4-20 X 1-7/8 WAFER SHCS
2	D-1/4-20 X 2-1/4 WAFER SHCS
8	E-1/4 FLAT WASHER
8	F-1/4-20 NYLOCK NUT




6 A-.27 X 2 SOCKET WAFER A




2 B-.27 X 3 SOCKET WAFER A




6 C-1/4-20 X 1-7/8 WAFER SHCS



2 D-1/4-20 X 2-1/4 WAFER SHCS



8 E-1/4 FLAT WASHER




8 F-1/4-20 NYLOCK NUT

Step 1

Lay seat on its side.
Attach front leg and back leg
to seat. Now flip seat around and
do the other side. Uses (6) 1-7/8" bolt, nut and washer


wing faces
forward



Step 3

Attach back to seat
using (2) .27x2" screws


Attach back to rear leg
using (2) .27x3" screws



Step 2

Attach arms to front leg using
(2) 2-1/4" bolt, nut and washer

arm hangs over wing



Step 4

Attach braces to legs
using (4) .27x2" screws

