


SHR22 - Seashell Rocker [59 lbs]



FURNITURE LEISURE INC
1.800.213.2401

www.FurnitureLeisure.com
www.PicnicFurniture.com
www.ParkTables.com

www.PoolFurnitureSupply.com
www.PicnicTableSupplier.com
www.UBrace.com

Model: SHR22


- (1) Seat
- (1) Back
- (2) Front legs
- (2) Arms
- (2) Rockers
- (1) Hardware pack




Qty.	Description
4	A - 8 X 1-1/2 PHIL FLAT SCREW
2	B - 1/4-20 X 3/4 WAFER SHCS
4	C - 1/4-20 X 1-1/4, BUTTON SHCS
2	D - 1/4-20 X 1-3/4 WAFER SHCS
10	E - 1/4-20 X 2-1/4 WAFER SHCS

ASSEMBLY INSTRUCTIONS


Step 1
Attach front legs to rockers with (4) 1 1/4" chair bolts. Make sure wing is toward the front of the rocker




Step 3
Attach rockers to seat using (4) 2 1/4" chair bolts




Step 5
Attach arms to back using (2) 1 3/4" chair bolts




Step 2
Attach front legs to seat using (6) 2 1/4" chair bolts.



Step 4
Attach arms to legs using (2) 3/4" chair bolts



Step 6
Attach back to seat using (4) 8 x 1 1/2" screws



HARDWARE IS COATED STAINLESS STEEL UNLESS OTHERWISE SPECIFIED

11/29/2012