


MODEL #: 6SPTGVP


1. THE PEDESTAL SHOULD BE SECURED TO THE CONCRETE. NOTICE THE DISTANCE FROM THE SEAT TO THE GROUND.
 2. ATTACH THE SEAT ARMS TO THE PEDESTAL. SEE FIG. 1 BELOW.
 3. ATTACH THE TOP ARMS TO THE TOP OF THE PEDESTAL.
 4. NOW ATTACH THE SEAT AND TOP PLANKING. SEE FIG. 2 BELOW FOR HARDWARE.
- NOTE: THE VINYL PLASTIC & FIBERGLASS TOPS ARE ONE PIECE. ALUM, WOOD & REC. PLASTIC HAVE 3 TOP PLANKS.



SM IN THE MODEL# DESIGNATES SURFACE MOUNT

FIGURE 2


6SPTGA - 6SPTGASM
2" x 10" ALUMINUM PLANK



5/16" x 1 1/4" CARRIAGE BOLT
HOLD DOWN CLIP & FLANGE NUT


6SPTGW - 6SPTGWSM
2" x 10" SYP TREATED PLANK

6SPTGRRP - 6SPTGRRPSM
2" x 10" RECYCLED PLASTIC PLANK




3/8" x 2 1/4" CARRIAGE BOLT
LOCK WASHER & NUT

6SPTGVP - 6SPTGVPSM
VINYL PLASTIC COATED STEEL



3/8" x 1 1/2" HEX BOLT
LOCK WASHER & NUT

6SPTGF - 6SPTGFMSM
FIBERGLASS SEATS & TOPS



3/8" x 2" LAG BOLT
LOCK WASHER & NUT