

USER GROUP: All Ages

RECOMMENDED CREW: 1 Person

TOOLS REQUIRED:

- T-25, T-30 Torx
- Level, Square, Wood Saw
- Auger / Post Hole Digger / Shovel
- Drill Bits: 5/32", 7/32"
- Framing, Bracing, or Concrete Forms (Not Included)
- High Speed 3/8" Electric Drill with Clutch

NOTE: Use of any other driver may result in damage to product, tool, and/or hardware!

NOTE: Apply Thread Locking Solution to ALL Non-Patched Hardware with Threads!


INSTALLATION TIME: 2 Hours

WEIGHT: 17 lbs. Each (68 lbs. Total)

CONCRETE REQUIRED: (7.3 or 12) 80lb. bags
(4.4 ft³ or 10.2 ft³)

NOTE: Concrete must have a minimum rating of 2,500 psi and must be mixed per manufacturer's recommendations.

ITEM	Part No.	QTY	DESCRIPTION
1	RSP-2364XX	8	Sheet - R3 Dog Park Hurdle Jump Panel
2	REP00365XX	8	Rec. Plastic 2" x 6" Leg for Dog Park Hurdle Jump
3	HWS0298	16	Screw - 1/4" x 1-1/2" RSS SS
4	HWS0300	16	Screw - 5/16" x 2-1/2" RSS SS



PRE-INSTALLATION CHECK:

Customer is responsible for verifying materials received by comparing received items with packing list. If any parts are missing or damaged, including documentation, contact your local sales representative immediately.


Supplier is not responsible for items discovered missing after 72 hours from time of delivery.

Before beginning installation, all installers must read and understand the Installation Introduction manual as supplied. If you did not receive a copy, or if you have any questions regarding any information in the Installation Instructions or this Installation Guideline, contact your local sales representative.

INSTALLATION GUIDELINE

STEP 1

Determine depth for setting support posts. Recommended minimum depth of support posts is 12". If support posts are set at 12" depth, cut off 6" from each support post. If support posts are set at 18" depth, support posts do not require modification.




INSTALLATION GUIDELINE



STEP 2

Mount panels to support posts. Ends of panels should be flush with sides of support post. Top edges of panels should be flush at top of hurdle. See Detail 2-1. At bottoms of panels, drill two (2) 7/32" pilot holes through pre-drilled holes in panel and into support post. Secure with two (2) 5/16" x 2-1/2" RSS. At tops of panels, drill two (2) 5/32" pilot holes through pre-drilled holes in panel and into support post. Secure with two (2) 1/4" x 1-1/2" RSS. See Detail 2-1. Repeat for all panels and support posts.

Detail 2-1



Detail 2-2



INSTALLATION GUIDELINE

STEP 3

Set support posts. Refer to site plan drawing and site elevation drawing for placement of all support posts. Installer is responsible for proper location of all support posts. Support post spacing is shown at right. Footing holes for support posts must be a minimum of 12" diameter and 12" deep. Footing holes should be 18" deep if support posts are not cut. Place assemblies into footing holes and plumb. Fill each footing hole with concrete to within 3" from ground surface. Allow concrete to cure based upon manufacturer's instructions. Backfill each footing hole with dirt, flush with grade. See Detail 3-1. Installation is complete.

Detail 3-1

