



LEAVE ALL BOLTS LOOSE UNTIL ALL ARE IN PLACE.

1. BOLT THE LEGS TOGETHER AS SHOWN WITH THE BRACE BETWEEN THE LEGS, (BENT END AWAY FROM THE LEG) AND THE TOP ANGLE FACING THE SAME WAY.
2. LAY FIBERGLASS TOP UPSIDE DOWN ON A NON-ABRASIVE SURFACE.
SET A TABLE LEG ON THE TABLE TOP. LINE UP THE TOP ANGLE HOLES W/ THE PREDRILLED PILOT HOLES.
ATTACH WITH 3/8" x 2" LAG SCREW. NOTE: YOU MAY NEED TO TAP THE SCREW WITH A HAMMER IN ORDER TO START THE SCREW INTO THE PILOT HOLE.
BE SURE TOP ANGLES FACE TOWARD THE CENTER.
ATTACH BRACES AT THIS TIME ALSO.
3. TURN THE TABLE OVER & ATTACH SEAT PLANKS WITH 3 1/2" LAG SCREWS.



ON AN 8' TABLE THE BRACES ARE 1 FT. APART AT THE CENTER. THERE WILL BE TWO PREDRILLED HOLES TO BOLT TO.

3/8" x 2"
HEX BOLT



8' TABLE BRACE DETAIL